



EXTERNAL KEYBOARD CONNECTOR - J1			
Pin No.	Desc.	Pin No.	Desc.
1	DOWN	2	UP
3	EXIT	4	MENU
5	PWR	6	LED_EN
7	GND	8	KEYBOARD VDD

BACKLIGHT PWM & POWER - J5			
Pin No.	Desc.	Pin No.	Desc.
1	GND	2	GND
3	EN	4	PWM
5	VDD	6	VDD

LIGHT SENSOR CONNECTOR - RT1			
Pin No.	Desc.	Pin No.	Desc.
1	GND	2	ADC_IN
3	NC	4	LIGHT SENSOR VDD

UART CONNECTOR - J2			
Pin No.	Desc.	Pin No.	Desc.
1	GND	2	RXD
3	TXD	4	VDD