



EXTERNAL KEYBOARD CONNECTOR - J5			
Pin No.	Desc.	Pin No.	Desc.
1	DOWN	2	UP
3	EXIT	4	MENU
5	PWR	6	LED_EN
7	GND	8	KEYBOARD VDD

BACKLIGHT PWM & POWER - J4			
Pin No.	Desc.	Pin No.	Desc.
1	VDD	2	VDD
3	EN	4	PWM
5	GND	6	GND